Mr./Mrs/Ms:	Model: Reg.No:
Invoice/Job no: _	Odometer reading: V.I.N:
Service type:	FS A B A B A B A B A B A B A B A B A B A



# **FREELANDER**

(ALL MODELS)

## **MAINTENANCE CHECK SHEET**

Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked \*

3/5 | 12/20 | 24/40 | 36/60 | 48/80 | 60/100 | 72/120 | 84/140 | 96/160

Months/,000 miles:

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost.

FS	FIRST SERVICE	Α	В	MAIN SERVICE (UNDER BONNET)
1. 5k	Replace engine oil and filter. Endorse service record - First 5000 kilometers only	30.		Check condition of Poly V ancillary driving belt
2. 5k	Where leaded fuel is used retune using Testbook - First 5000 kilometers only	31.		Renew Poly V ancillary driving belt - L Series Diesel, Every 80,000 kilometers
А В	MAIN SERVICE (VEHICLE INTERIOR)	32.	160k	Renew Poly V ancillary driving belt
3.	Check condition and security of seats and seat belts - 36 months and then every 12 months	33.		Replace Camshaft and Rear Fuel Injection Pump drive belts - L Series Diesel, every 80,000 kilometers
4	Check operation of all lamps, horns and warning indicators	34.	120k	Replace Camshaft drive belt - 1.8/KV6
5	Check operation of front/rear wipers and washers and condition of wiper blades	35.		Check/top up brake and PAS levels
5.	Check operation of handbrake	36.		Check/top up intermediate reduction drive, gearbox and rear axle oil
7	Replace alarm handset batteries	37.	160k	Renew manual gearbox oil - <b>GETRAG</b>
8	Adjust handbrake - First 20,000 kilometers only	38. 100	k 200k	Renew automatic gearbox oil
9.	Renew pollen filter - If fitted	39.		Check visually clutch pipe/unions for chafing, leaks and corrosion
10.	Check operation of ignition key interlock	40.		Check and top up windscreen and rear washer reservoir
10.	MAIN SERVICE (VEHICLE EXTERIOR)	41.		Check battery condition and clean/grease battery terminals
	,	42.		Visually check intercooler/radiator for external obstructions
11.	Annual corrosion/cosmetic inspection - Only on vehicles sold after 21/11/98	43.		Renew engine oil and filter
12.	Remove road wheels	44.		Check brake and fuel hoses, pipes and unions
13	Check tyre pressures and adjust if necessary, including spare (bar)	45.		Check exhaust system for leaks, security and condition
	LHF RHF RHR LHR Spare	46.		Check suspension and steering for signs of leaking or wear
14.	Check tyre for damage and tread depth, including spare (mm)	47.		Check PAS system for signs of leaking and condition
	LHF RHF RHR LHR Spare	48.		Check road wheel speed sensor electrical harness for damage - ABS only
15.	Inspect brake pads for wear, calipers for leaks and discs for condition	49.		If fault lamp(s) are illuminated, interrogate that system using TestBook and report findings (subject to additional charge)
16	Inspect rear brake shoes via back plate inspection point	50.		Replace brake fluid - Every 60,000 kilometers
17.	Remove rear brake drums, inspect shoes for wear/drums for condition	51	ī	Carry out road test - See workshop manual maintenance section
18. 200k		52	ī	Endorse service record
19	Apply anti seize compound. Refit front road wheels to original positions and rear road	53.	ī	Report any unusual features of vehicle
	wheels to OPPOSITE sides of rear axle (Ref. Bulletin 0008 - Suspension)	00.		10 YEAR REPLACEMENT - AIRBAGS
20.	Lubricate hinges, check straps and bonnet catch			Replace airbag module(s) after 10 years reguardless of mileage*
21.	Lubricate sunroof guide rails, slides and seal	54.	╡┝═╡	Replace seatbelt pre-tensioners after 10 years regardless of mileage*
22	Clean sunroof drain tubes and channels	55. L		Replace sealbeit pre-tensioners after 10 years regardless of filleage
	MAIN SERVICE (UNDER BONNET)			s listed, are those recommended for vehicles operating under normal driving, road and climatic conditions. More be necessary if the vehicle is subject to stop/start operation, extremes of temperature, dusty conditions, off road
23. 60k 120k	Renew coolant	•	-	be necessary in the vehicle is subject to stopistant operation, extremes of temperature, dusty conditions, on roadi ig of trailers.
24.	Check cooling, intercooler and heating systems for leaks, hoses for security and condition. Top up as required	•	·	d, cosmetic/corrosion inspection check completed and service portfolio book endorsed
25. 120k	Renew spark plugs - 1.8			
26. 100k	Renew spark plugs - KV6	Name:		Signature: Date:
27.	Renew fuel filter element - L Series Diesel			

02/01

100k

29.

200k

Renew fuel filter element - Td4 Diesel

Renew air cleaner element and clean drain holes

### **GLOSSARY**

FIRST SERVICE= The first service required after sale of vehicle. This service is only applicable to certain models as indicated by the maintenance check sheet.

**LUBRICATION SERVICE** = The lubrication service is carried out between main services, the first at 18 months or 18,000 miles, whichever occurs first, and then at every subsequent 12 months or 12,000 miles. It is only applicable to certain derivatives as indicated by the maintenance check sheet.

MAIN SERVICE = The main service is applicable to all vehicles. It is carried out at 12 month or 12,000 miles intervals, whichever occurs first.

Main Service "A"is applicable at 12 months/12,000 miles, 36 months/36,000 miles, 60 months/60,000 miles 84 months/84,000 miles and so on.

Main Service "B"is applicable at 24 months/24,000 miles, 48 months/48,000 miles, 72 months/72,000 miles, 96 months/96,000 miles and so on. Some items do not need to be carried out at every main service and these items are identified by an indicator in the tick box e.g. 60k (This indicates that this item is only applicable every 60 months/ 60,000 miles)

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.

#### IMPORTANT

#### **OIL CHANGE DIESEL ENGINES**

If the vehicle is operated on fuel with a high sulphur content (over 0.5%) the oil change intervals must not exceed 10,000 Km (6000 miles)