Service type: FS A B A B A B A B	Invoice/Job no: V.I.N: V.I.N:	 Mr./Mrs/Ms: Model: Reg.No:
		Reg.No:



## (ALL MODELS 97MY TO 01MY) FREELANDER

MAINTENANCE CHECK SHEET

Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked \*

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost.

FIRST SERVICE	⊳	80	MAIN SERVICE (UNDER BONNET)
Replace engine oil and filter. Endorse service record - First 5000 kilometers only	30.		Check condition of Poly V ancillary driving belt
Where leaded fuel is used retune using Testbook - First 5000 kilometers only	31.	L	Renew Poly V ancillary driving belt - L Series Diesel, Every 80,000 kilometers
MAIN SERVICE (VEHICLE INTERIOR)	. —	160k	Renew Poly V ancillary driving belt
Check condition and security of seats and seat belts - 36 months and then every 12	33.		Replace Camshaft and Rear Fuel Injection Pump drive belts - L Series Diesel, every 80,000 kilometers
Check operation of all lamps, horns and warning indicators	34.	120k	Replace Camshaft drive belt - 1.8/KV6
Check operation of front/rear wipers and washers and condition of wiper blades	35.		Check/top up brake and PAS levels
Check operation of handbrake	36.		Check/top up intermediate reduction drive, gearbox and rear axle oil
Replace alarm handset batteries	37. L	160k	Renew manual gearbox oil <b>- GETRAG</b>
Adjust handbrake - First 20,000 kilometers only	100k	200k F	Renew automatic gearbox oil
Renew pollen filter - If fitted	39.		Check visually clutch pipe/unions for chafing, leaks and corrosion
Check operation of ignition key interlock	40.		Check and top up windscreen and rear washer reservoir
MAIN SERVICE (VEHICLE EXTERIOR)	\$ <del>1</del>		Crieck battery condution and cleanly lease battery terminals  Visually check intercooler/radiator for external obstructions
Annual corrosion/cosmetic inspection - Only on vehicles sold after 21/11/198	43 !		Renew engine oil and filter
Remove road wheels	44.		Check brake and fuel hoses, pipes and unions
Check tyre pressures and adjust if necessary, including spare (bar)	45.		Check exhaust system for leaks, security and condition
LHF RHF RHR LHR Spare Spare	46.		
ek tyle loi dalliage allu ilead depili, ilicidd	4.		Check and whool appear plantical between for demand.
LHF RHF RHR LHR Spare	. 48.		Crieck load wrieer speed sersor electrical rialitiess for darriage <b>- Abs only</b> If fault lamn(s) are illuminated interrogate that system using TestBook and report
Inspect brake pads for wear, calipers for leaks and discs for condition			findings (subject to additional charge)
Inspect rear brake snoes via back plate inspection point	50.		Replace brake fluid - Every 60,000 kilometers
Remove rear brake drums, inspect snoes for wear/drums for condition	51.		Carry out road test - See workshop manual maintenance section
Apply anti-pains personal Defit front road wheele to existing positions and roat road	52.	L	Endorse service record
Apply and seize compound. Relit front road wheels to original positions and rear road wheels to OPPOSITE sides of rear axle (Ref. Bulletin 0008 - Suspension)	53.		Report any unusual features of vehicle
Lubricate hinges, check straps and bonnet catch			10 YEAR REPLACEMENT - AIRBAGS
Lubricate sunroof guide rails, slides and seal	54.		Replace airbag module(s) after 10 years reguardless of mileage*
Clean sunroof drain tubes and channels	55.		Replace seatbelt pre-tensioners after 10 years regardless of mileage*
MAIN SERVICE (UNDER BONNET)	The maintenance	e items li	The maintenance items listed, are those recommended for vehicles operating under normal driving, road and climatic conditions. More
Renew coolant	frequent attention may be necessardriving or frequent towing of trailers.	n may be	necessary if the vehicle is subject to stop/start operation, extremes of temperature, dusty conditions, off road of trailers.
Check cooling, intercooler and heating systems for leaks, hoses for security and condition. Top up as required	Service check completed, cosmetic/corros	mpleted,	cosmetic/corrosion inspection check completed and service portfolio book endorsed
Renew spark plugs - 1.8			
Renew spark plugs - KV6	Name:		Signature: Date:
Renew fuel filter element - L Series Diesel			

13 12 11 13 12 11

7. 9. 10.

9 5 4

ω

Ş Ş

σ

FS

FIRST SERVICE

4

02/01

29. 28. 27.

Renew fuel filter element - Td4 Diesel

Renew air cleaner element and clean drain holes

25. 26.

100k

120k

23. 24.

60k

120k

20. 21. 22.

17. 16. 15.

18.

## JLUSSAKT

FIRST SERVICE= The first service required after sale of vehicle. This service is only applicable to certain models as indicated by the maintenance check sheet.

subsequent 12 months or 12,000 miles. It is only applicable to certain derivatives as indicated by the maintenance check sheet. LUBRICATION SERVICE = The lubrication service is carried out between main services, the first at 18 months or 18,000 miles, whichever occurs first, and then at every

MAIN SERVICE = The main service is applicable to all vehicles. It is carried out at 12 month or 12,000 miles intervals, whichever occurs first.

Main Service "A" is applicable at 12 months/12,000 miles, 36 months/36,000 miles, 60 months/60,000 miles 84 months/84,000 miles and so on.

Main Service "B"is applicable at 24 months/24,000 miles, 48 months/48,000 miles, 72 months/72,000 miles, 96 months/96,000 miles and so on. Some items do not need to be carried out at every main service and these items are identified by an indicator in the tick box e.g. 60k (This indicates that this item is only applicable every 60 months/ 60,000 miles)

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual

## MPORTAN

## OIL CHANGE DIESEL ENGINES

If the vehicle is operated on fuel with a high sulphur content (over 0.5%) the oil change intervals must not exceed 10,000 Km (6000 miles)